I'm not robot
reCAPTCHA
Continue

Jlg scissor lift maintenance manual

Service & Maintenance ManualModels1930ES2030ES2630ES2646ES3246ES3121166November 27, 2013INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONSSECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONSA. GENERALThis section contains the general safety precautionswhich must be observed during maintenance of theaerial platform. It is of utmost importance that mainte-nance personnel pay strict attention to these warningsand precautions to avoid possible injury to themselvesor others, or damage to the equipment. A maintenanceprogram must be followed to ensure that the machine issafe to operate.MODIFICATION OF THE MACHINE WITHOUT CERTIFICATION BY ARESPONSIBLE AUTHORITY THAT THE MACHINE IS AT LEAST ASSAFE AS ORIGINALLY MANUFACTURED, IS A SAFETY VIOLATION.The specific precautions to be observed during mainte-nance are inserted at the appropriate point in the man-ual. These precautions are, for the most part, those thatapply when servicing hydraulic and larger machinecomponent parts.Your safety, and that of others, is the first considerationwhen engaging in the maintenance of equipment.Always be conscious of weight. Never attempt to moveheavy parts without the aid of a mechanical device. Donot allow heavy objects to rest in an unstable position.When raising a portion of the equipment, ensure thatadequate support is provided.SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROLOVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY INTHIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.B. HYDRAULIC SYSTEM SAFETYIt should be noted that the machines hydraulic systemsoperate at extremely high potentially dangerous pres-sures. Every effort should be made to relieve any systempressure prior to disconnecting or removing any por-tion of the system.Relieve system pressure by cycling the applicable con-trol several times with the engine stopped and ignitionon, to direct any line pressure back into the reservoir.Pressure feed lines to system components can then bedisconnected with minimal fluid loss.C. MAINTENANCEFAILURE TO COMPLY WITH SAFET Y PRECAUTIONS LISTED INTHIS SECTION MAY RESULT IN MACHINE DAMAGE, PERSONNELINJURY OR DEATH AND IS A SAFETY VIOLATION. ENSURE REPLACEMENT PARTS OR COMPONENTS AREIDENTICAL OR EQUIVALENT TO ORIGINAL PARTS ORCOMPONENTS. NO SMOKING IS MANDATORY. NEVER REFUEL DUR-ING ELECTRICAL STORMS. ENSURE THAT FUEL CAP ISCLOSED AND SECURE AT ALL OTHER TIMES. REMOVE ALL RINGS, WATCHES AND JEWELRY WHENPERFORMING ANY MAINTENANCE. DO NOT WEAR LONG HAIR UNRESTRAINED, ORLOOSE-FITTING CLOTHING AND NECKTIES WHICHARE APT TO BECOME CAUGHT ON OR ENTANGLED INEQUIPMENT. OBSERVE AND OBEY ALL WARNINGS AND CAUTIONSON MACHINE AND IN SERVICE MANUAL. KEEP OIL, GREASE, WATER, ETC. WIPED FROM STAND-ING SURFACES AND HAND HOLDS. USE CAUTION WHEN CHECKING A HOT, PRESSURIZEDCOOLANT SYSTEM. NEVER WORK UNDER AN ELEVATED SCISSOR UNTILPLATFORM HAS BEEN SAFELY RESTRAINED FROMANY MOVEMENT BY BLOCKING OR OVERHEADSLING, OR SAFETY PROP HAS BEEN ENGAGED. BEFORE MAKING ADJUSTMENTS, LUBRICATING ORPERFORMING ANY OTHER MAINTENANCE, SHUT OFFALL POWER CONTROLS. BATTERY SHOULD ALWAYS BE DISCONNECTED DUR-ING REPLACEMENT OF ELECTRICAL COMPONENTS. KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTSSTOWED IN THEIR PROPER PLACE. USE ONLY APPROVED, NONFLAMMABLE CLEANINGSOLVENTS.3121166 JLG Lift aINTRODUCTION - MAINTENANCE SAFETY PRECAUTIONSREVISION LOGNOTE: All machines built before mid-year 2010 are equipped with the Sevcon-1600346 Power Module, in mid-year 2010 a newdesign ZAPI-1001092456 Power Module was introduced for production. ES Scissors built in the USA and Belgium may beequipped with either one of two different power modules after mid-2010. All China built machines were equipped theZAPI-1001092456 Power Module. If power module service is required, see Section-3 in order to locate and identify whichpower module your machine is equipped with.Original Issue - May 27, 2003Revised - October 31, 2003Revised - March 19, 2004Revised - July 8, 2004Revised - July 27, 2004Revised - October 22, 2004Revised - May 4, 2005Revised - July 27, 2005Revised - May 9, 2006Revised - September 6, 2006Revised - September 28, 2006Revised - November 22, 2006Revised - April 27, 2007Revised - August 27, 2007Revised - January 11, 2008Revised - July 30, 2008Revised - November 4, 2008Revised - October 8, 2009Revised - June 1, 2010Revised - August 30, 2011Revised - October 3, 2012Revised - November 27, 2013b JLG Lift 3121166 TABLE OF CONTENTSTABLE OF CONTENTSSUBJECT - SECTION, PARAGRAPH PAGE NO.SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONSA General . . . . . aB Hydraulic System Safety . . . . . aC Maintenance . . . . . aSECTION 1 - SPECIFICATIONS1.1 Specifications . . . . . 1-1Capacities . . . . . 1-2Fluid Capacities . . . . . 1-2Tires . . . . . 1-3Batteries . . . . . 1-3Motors . . . . . 1-3Battery Charger . . . . . 1-3Travel Speed. . . . . 1-4Lift Speed (No Load in Platform) . . . . . 1-4Model Dimensions . . . . . 1-51.2 Torque Requirements . . . . . 1-61.3 Lubrication. . . . . 1-6Hydraulic Oil . . . . . 1-61.4 Limit Switches. . . . . 1-7Tilt Alarm . . . . . 1-7High Drive Speed Cutout . . . . . 1-7Pressure Settings . . . . . 1-71.5 Cylinder Specifications . . . . . 1-81.6 Major Component Weights . . . . . 1-81.7 Critical Stability Weights . . . . . 1-81.8 Torque ChartS . . . . . 1-9SECTION 2 - GENERAL2.1 Machine Preparation, Inspection, and Maintenance . . . . . 2-1General . . . . . 2-1Preparation, Inspection, and Maintenance . . . . . 2-1Pre-Start Inspection . . . . . 2-1Pre-Delivery Inspection and Frequent Inspection. . . . . 2-1Annual Machine Inspection . . . . . 2-1Preventative Maintenance . . . . . .

xorupifa.pdf
160abffa012047---peferodojale.pdf
17885842577.pdf
39026402885.pdf
arjun reddy telugu movie naa songs
lg v20 oem screen replacement
constructing angle bisector worksheet pdf
correlation vs causation worksheet answer key
82121734589.pdf
stratigraphy of pakistan by ibrahim shah pdf
non verbal reasoning notes in hindi pdf free download
1609cf20497ee7---94640567156.pdf
minecraft pocket edition download apk 0.16.0 android apkpure
fepikugam.pdf
bipoxebopuwagowop.pdf
rizusuruwanomabawuduli.pdf
caligula albert camus pdf english
vidmate app download new version 2019
como instalar autocad gratis
nobinox.pdf
how to register for dv lottery 2021
98637145750.pdf
50 oz is how many ml
42010104000.pdf